

Lipstick Camera Light

Data Sheet

for PN 22293026

Purpose

The Lipstick Camera Light illuminates the viewing area for the lipstick video camera. The adjustable mounting bracket enables you to change the position and angle of the area of illumination.


Adjustments

The Lipstick Camera Light may be repositioned either by rotating it around the camera, or tilting it toward or away from the camera lens.

Light Position

The light can be repositioned by rotating it around the camera body. To change the position of the light relative to the camera body:


1. Loosen the screws indicated at right.
2. Manually rotate the light around the camera to the desired position.
3. When the desired position is achieved tighten the screws.



Light Angle

The light can be angled toward or away from the camera lens. To adjust the angle of the light relative to the camera lens:

1. Loosen the tilt adjust screw indicated at right.
2. Manually reposition the light toward or away from the camera lens.
3. When the desired angle is achieved, tighten the screw.



Maintenance

DAILY After turning OFF system power:

- clean the light body with a soft dry cloth.
- clean the light lens, as needed, using lens cleaning paper.

Specifications

Power Source 12V DC, 50 mA